



FOR CLUTCH AND BRAKE PEDALS
WELD ON A M8 BOLT WITH A 3MM
HOLE DRILLED. FEED THROUGH THE
CABLE, AND TIGHTEN THE WASHER
AND NUT, CLAMPING THE CABLE.

FOR THE THROTTLE/
ACCELERATOR
A 3MM HOLE CAN
BE DRILLED INTO THE
PEDAL, AND THE CABLE
CAN BE FED THROUGH.

KARTBUILDING
FREE RACING KART PLANS

PEDALS		www.kartbuilding.net
DRG. NO.: 18	DATE: 24/07/03	© STEPHEN BURKE