


Steering Arm (Column)
Total Length: 451mm [17.755in]
Diameter: 9mm [0.35in]

Optionally, grind flat a small area to help attach the steering wheel.

Steering Wheel to be bolted to the steering column.

Thin Plywood (1.5mm [0.05in]), cut to shape (above). Bend carefully into shape. Use small nails & glue to secure in place.



To help with the construction of the Bonnet Assembly, extra pieces of plywood can be used to help position and secure the "Bonnet-Rear", "Bonnet-Center" and "Bonnet-Front" parts, before the thin plywood cover is bent into shape.

Thin plywood/board which can be easily bent into shape can be obtained. Otherwise it can be difficult to form the shape required. Steam can be used as an option to help in the bending process.

PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF THE DESIGNER. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF THE DESIGNER IS PROHIBITED.		kartbuilding.net 	
TITLE: BONNET ASSEMBLY 2			
MATERIAL AS SPECIFIED		DATE: 26/10/2010	
FILE NAME: WOODEN-PUSH-CART		SIZE: A4	REV. 1
SCALE: 1:2	DESIGNER: STEPHEN BURKE		SHEET 9 OF 10

